

## **DIESEL-EN - User Manual**

---

*MOTOR-DRIVEN PUMP START-UP PANEL*

**- STANDARD EN 12845 -**



# CONTENTS

1.	INTRODUCTION.....	5
2.	WARNINGS .....	6
3.	GENERAL DESCRIPTION .....	7
4.	INSTALLATION.....	8
5.	CONTROL UNIT USER MANUAL .....	9
6.	APPENDED 1 –ASSOCIABLE CONTACT .....	23
7.	APPENDED 2 – EVENTS HISTORY .....	25
8.	APPENDED 3 – WEEKLY AUTOMATIC TEST .....	28
9.	APPENDED 4 – SPECIAL FUNCTIONS AND RESTORATION .....	30



# 1. INTRODUCTION

This manual must always accompany the relevant equipment and be conserved in an accessible location for consultation by qualified technicians assigned for operation and maintenance of the system.

The installer/user is strongly recommended to carefully read all instructions and information in this manual before using the product, in order to avoid damage or improper use of the unit, which would also render the warranty null and void.

Before operating the equipment, carefully read the manual and follow all instructions provided.

The information and instructions in this manual refer to the standard use of this product; in the event of special circumstances, functions or applications not described in this document, contact our service center for assistance.

If technical assistance or spare parts are required, when contacting the manufacturer always specify the identification code of the model and construction number as stated on the data plate.

Our service center is available for any requirement or clarification.

On receipt of the goods, inspect immediately to ensure that the equipment has not been damaged during transport. If defects are found, the client should promptly notify our retailer within 5 days of receiving the goods, or in the event of direct purchases, the producer service center.



**N.B.** the information provided in this manual is subject to modifications without notice. The manufacturer shall not be held liable for any damage caused in relation to the use of these instructions, as they are to be considered guideline only. Note that failure to observe the instructions provided in this manual may cause physical injury or damage to objects.

In any event all local and/or current legislation must be observed at all times.

## 2. WARNINGS



The electrical panel must be used exclusively for the purpose and function as specified in design. Any other application or use is to be considered improper and therefore hazardous.

In the event of a fire in the place of installation or the surrounding area, avoid the use of water jets and use the appropriate extinguishing equipment and means (powder, foam, carbon dioxide).

Install the equipment far from heat sources and in a dry and sheltered location in observance of the stated protection rating (IP).

The installation of a safety device is recommended to protect the panel power line in compliance with current electrical standards.

The electrical panel must be connected by a qualified electrician in observance of the relevant electrical standards.

No parts of the panel must be disassembled without the official authorization of the producer: any tampering with or modifications to the unit will render all terms of the warranty null and void.

All installation and/or maintenance operations must be performed by a specialized technician who is fully aware of the relevant current safety standards.

Ensure the installation is connected to an efficient earthing system.

After making the electrical connection, check that all electrical panel settings are correct to avoid automatic start-up of the electric pump.

The producer declines all liability in the event of the following:

- Incorrect installation;
- Use by personnel not adequately trained in the correct use of the panel;
- Serious failure to perform scheduled maintenance;
- Use of non-original spare parts or parts not specific to the model;
- Unauthorized modifications or interventions;
- Partial or total failure to observe instructions.

### 3. GENERAL DESCRIPTION

- Power supply 1 ~ 50/60Hz 230V±10%;
- Low voltage control circuits and inputs;
- 2 normally closed inputs for control of the start-up pressure switches;
- 2 inputs from external batteries for starter motor and aux. circuit power supply;
- Input for command from priming tank;
- Input for signal from pressure switch to indicate system under pressure / motor-driven pump off;
- AUT-MAN key selector;
- Motor-driven pump manual start and stop buttons;
- Fault reset button;
- Manual start-up test button (enabled in the event of automatic start failure);
- Control unit led test button;
- Buttons for start-up in Manual Emergency mode protected by “Safe crash”;
- Back-lit LCD display, for viewing: 2 battery volt meters, 2 battery ammeters, rev counter, total and partial hour counter, fuel level gauge, water thermometer, oil thermometer, oil pressure gauge, battery start counter, event log;
- Indicator leds;
- Option of operation compliant with UNI10779;
- Display with 5 languages: Italian, English, French, Spanish, German;
- Settable delay and alarm functions;
- Alarm outputs for: automatic mode disabled, control panel fault, motor-driven pump running, start-up failure;
- 2 battery chargers 12Vdc 3A (24Vdc 3A for version at 24V);
- Protection of aux. circuits and motor with fuses;
- Door lock general disconnect switch;
- Metal enclosure (IP55);
- Ambient temperature: -5/+40 °C;
- Relative humidity 50% at 40 °C (condensate free).

## 4. INSTALLATION

**Ensure that the mains power supply specifications correspond to the voltage specified on the data plate of the electrical panel and motor connected, then make the earthing connection before all other connections.**

DIESEL-EN



1~230V ± 10% 50/60Hz

The power line must be protected by a residual current circuit breaker.

Tighten the electrical cables on the relative terminals using a suitable tool correctly sized to avoid the risk of damage to the fixing screws. Take care if using an electric screwdriver.

The electrical panel is designed for wall-mounting using screws and plugs in the pre-drilled holes at the corners of the enclosure, or by means of brackets when present.

Install the equipment in areas compliant with the protection rating and ensure that the box is kept intact when drilling the holes for fitting the cable clamps.

Avoid the use of multicore cables where there are wires connected to inductive loads and power cables and signal cables such as sensors and digital inputs.

Keep connection cables as short as possible, preventing any twisting of cables which may be harmful due to inductive effects on the electronic equipment.

All wires used in the cabling must be suitably sized to withstand the load to be powered.

Make the earthing connection before all other connections.


Ensure that the power cable is able to withstand 150% of the maximum motor current (according to EN 12845 Para. 10.8.4) and connect it to the terminals of the main disconnect switch of the electrical panel.

## 5. CONTROL UNIT USER MANUAL



# MONITORING AND CONTROL UNIT FIRE-FIGHTING MOTOR PUMP IN CONFORMITY TO UNI EN 12845 STANDARD TYPE C-12845-485

INSTRUCTION AND USER MANUAL




COMPLETE OF:


- two battery ammeters
- two battery voltmeters
- total hour meter
- partial hour meter
- tachometer
- water thermometer
- oil thermometer
- oil pressure gauge
- fuel level indicator

- Automatic start with 6 impulses alternated on the two batteries.
- Manual start-up buttons.
- Test button.
- Button for in-site test for machine putting into service.
- Manual stop with button.
- Check of efficiency of the batteries.
- Engine automatic faults surveillance.
- History events.

# BRIEF INSTRUCTIONS



## COMPONENTS TO BE FITTED EXTERNALLY



\*PARAGRAPH NUMBER (OF REGULATION EN12845) TO CONSULT

## HISTORY AND REVISIONS


Date	Level of the REVISION	Description	Page
December 2007		See manual without revision	
January 2008	2.12	Terminal 50 pump pressure switch connection	6
		Possibility of having the pump pressure switch off or on	enclosure A
		ENGINE AND PUMP IN OPERATION (Detection of pump running with pressure switch). Alarms: PUMP FAULT, PRESSURE WITH ENGINE STOPPED	enclosure E
		Weekly test: We have removed the connections with terminals 22 23 24	enclosure D
		Zeroing historical report (visible with remote management)	enclosure F
		Stopping at the reopening of the float of the priming tank	enclosure G
		Inclusion - exclusion of the stopping from priming float	enclosure A
		Stopping operation UNI10779 with switch AUTOMATIC START UP ENGAGED	3
July 2008	2.13	Delay in closing or opening the contact of the priming tank float	8
October 2008	2.14	Contact associable with the running engine or the general alarm	enclosure H
		If both the batteries are in the fault "INEFFICIENT BATTERY", the startings continue all the same until the starting failure	4
		Correction: with WATER RESERVE or FUEL RESERVE or NO FUEL or STARTING FAILURE, the relay "PANEL FAULT" was not restored.	
December 2008	2.15	Fuel float interruption control	
May 2010	2.16	Portuguese added	10
April 2011	2.17	A programmable de-energization time of contacts 22 23 24 is entered when the stopped engine is detected.	8
September 2012	2.18	Weekly automatic test – stop during the test. Procedure run to show and reset the events history.	enclosure D - 9 enclosure B/C-F -10

Valid for firmware revisions higher than or equal to 2.18

# INSTRUMENTS

<ul style="list-style-type: none"> <li>• <b>A and B BATTERIES AMMETERS</b></li> <li>• <b>A and B BATTERIES VOLTMETERS</b></li> <li>• <b>TOTAL HOUR METER</b></li> <li>• <b>PARTIAL HOUR METER</b></li> <li>• <b>TACHOMETER</b></li> <li>• <b>FUEL LEVEL INDICATOR</b></li> <li>• <b>WATER OR OIL THERMOMETER</b></li> <li>• <b>OIL THERMOMETER</b></li> <li>• <b>OIL PRESSURE GAUGE</b></li> <li>• <b>A and B BATTERIES STARTUPS COUNTER</b></li> </ul>	<p>Full scale current 99A</p> <p>For voltages between 9 and 38 Volt.</p> <p>With four figures and a maximum reading (hours and minutes) of 9999.</p> <p>With four figures and a maximum reading (hours and minutes) of 9999.</p> <p>Full scale 9990 revolutions</p> <p>Displays the percentage of fuel present in the tank (full scale 100%)</p> <p>Displays engine oil or water temperatures 30 ÷ 140°C.</p> <p>Displays engine oil pressure up to 9 bars</p> <p>Displays the number of startups that have occurred up to 9999</p>	<p>} connected with the battery chargers Type CBS .....</p>
---	---	---

## SIMULTANEOUS READING OF THE INSTRUMENTS

<ul style="list-style-type: none"> <li>• BATTERY AMMETERS</li> <li>• BATTERY VOLTMETERS</li> <li>• FUEL LEVEL INDICATOR</li> <li>• HOUR METER</li> </ul> <p><b>WITH ENGINE RUNNING</b></p> <ul style="list-style-type: none"> <li>• TACHOMETER</li> </ul>		<p>Press to show the instruments</p>
---	--	--------------------------------------

FUNCTION AUTOMATIC STOP	JUMPER 	JUMPER NOT CUT	JUMPER CUT
<p>ALLOWED BY THE STANDARD <b>UNI 10779 July 2007</b></p> <p>When necessary, for any activities that are not constantly manned, automatic stopping is permitted, providing the pumping system is used exclusively by the hydrant system.</p>		<p>(Factory setting)</p> <p>AUTOMATIC STOP NOT ACTIVATED</p>	<p>(During the led test <b>UNI 10779</b> appears on the display)</p> <p>AUTOMATIC STOP ACTIVATED</p>
<p><b>OPERATION</b> (With automatic start up engaged)</p> <p>The motor pump stops 20 mins. after the contacts of the call pressure switches have been permanently closed. The display continuously shows how much time is left before the motor pump stops. The stop electromagnet remains energized for 15 seconds after detecting that the engine has stopped. The motor pump is not stopped when the switch is positioned on AUTOMATIC MODE EXCLUDED. When the switch is positioned back to AUTOMATIC START UP ENGAGED, the motor pump continues to run.</p>			

## OPERATION

### PREPARATION FOR AUTOMATIC

Active with the switch AUTOMATIC STARTUP ENGAGED (from this position it is possible to remove the key), setting the switch to excluded, the automatic start is blocked. This exclusion is signalled by the flashing warning light  and by the following message displayed on the screen: AUTOM. STARTING EXCLUDED.

### AUTOMATIC

When the equipment detects the opening of the starting call contact (pressure switches), the pump set begins to start up. The control unit checks (without commanding the stopping of the motor pump unit) for possible engine faults, during its operation

### MANUAL STARTING

This can be done in three ways:

- through the emergency start push-buttons.
- through the push-buttons START A or START B

- through the test push-button with consent of the associated warning light . The test push-button receives the consent after the engine automatic startup (activated by the call pressure switches), followed by the turning off or after start failure. In both conditions the relative warning light  turns on. The circuit used to this end automatically becomes non-operative and the warning light turns off, when the test button is pressed and the motor is found running.

### AUTOMATIC STARTING

This takes place when the CALL pressure switch contacts are opened, which is shown by a fixed light coming on . After the pressure switches have closed, the indicator starts to flash.

Automatic starting also happens when the pump priming float contact is closed, which is shown by a fixed light  coming on. When the contact opens, the indicator starts to flash. Flashing lights stay on for the whole time the motor is running.

In order to facilitate the startup, a specific circuit makes a sequence of 6 impulses automatically alternating on batteries A and B with 15 seconds cycles (5 secs. Startup, 10 secs. pause, both adjustable).

Engine starting is interrupted if the starter motor pinion does not succeed in engaging with the crown gear of the handwheel. After the first failure to engage, the starter motor makes a further five engagement attempts. At the sixth failure to engage the starter motor continues running for 5 seconds.

If a battery is found to fail during start-up, it is automatically suspended and the starting cycle proceeds on the other battery. If both the batteries are in the fault "INEFFICIENT BATTERY", the starting continue all the same until the starting failure

### DETECTION OF MOTOR PUMP RUNNING

The motor pump ON mode is monitored through a magnetic sender (pick-up TM30.....) and it disconnects the starter motor.

### STOP

THE ENGINE CAN ONLY BE TURNED OFF MANUALLY.

**It is not possible to stop it when the call from the pressure switches is present and automatic start up engaged.**

**With call from the pressure switches present**

Pressing the STOP pushbutton, the following message is displayed on the screen: DON'T SWITCH OFF IN EVENT OF FIRE ---STOP EXCLUDED.

• **With call from the pressure switches absent.**

Pressing the STOP pushbutton, the following message is displayed on the screen: DON'T SWITCH OFF IN EVENT OF FIRE.

### PARTIAL HOUR METER

Press  to select (PARTIAL HOUR METER) the operating hours and minutes of the last run of the motor pump. The hours indicated are zero-set the next time the motor pump is started up.

## OPERATION

### BATTERY CHARGING

Automatic charging: fast charging is controlled in current, intermediate and maintenance charging in voltage. The anomalies:

- battery A and/or FU1 blown
  - battery B and/or FU2 blown
- } detachment of battery cables and fuses blown
- short circuit of A and B battery cables
  - mains failure battery chargers A and B,

are signalled by the warning lights: anomaly ,  FAULT and they are displayed.

### BATTERIES CHECK

A special circuit checks the efficiency of the batteries, in particular DURING THE STARTING PHASE.

### ALARMS

The alarms are indicated on the display by the relative led and by a flashing cumulative led.

They are divided into four groups

- STORED: inefficiency of batteries A and B  
- NOT STORED AND ALWAYS ENABLED: minimum fuel level , mains power failure to the battery chargers A and B , PICK-UP interrupted, oil or water heater failure  and battery chargers A and B fault.
- CHECKED 10 SECONDS AFTER DETECTING ENGINE RUNNING AND STORED: insufficient oil pressure , charging alternator failure  and PICK-UP fault.
- CHECKED WITH ENGINE RUNNING AND STORED IMMEDIATELY: engine overtemperature .

### STARTUP FAILURE

It locks the starting cycle, if the engine has not started after the sixth attempt  .  
The starting cycles are released using the reset button, or the next time the motor is found to be running.

### RESET

The memorized protections are reactivated, by pressing the RESET button.

### REMOTE AUXILIARY FUNCTIONS With switching without voltage contacts

- **Automatic start-up disabled** (automatic start-up switch disabled   )
- **Start up failure**
- **Pump operative**
- **Switchboard fault:** occurred engine alarms (excluded minimum fuel level), not powered control unit, battery charger fault: mains failure, FLAT CABLE not connected and blown fuses (the battery charger fuses are signalled as: CHARGER BATTERY FAULT and INEFFICIENT BATTERY).
- **Minimum fuel level.**

### TEST

#### IN-SITE COMMISSIONING TEST

**Programming** move the DIP Switch 9 to ON.

Press the button  (the screen displays COMMISSIONING TEST) isolating the fuel supply (move the relative lever towards motor stop by hand, or hold down the stop button),

keep pressed (about 3 secs) the button  until the starter motor starts, a circuit produces 6 alternate impulses on the batteries A and B with 30-second cycles (15 secs. startup and 15 secs. pause).

**WARNING DO NOT** use the stop button with electro-stop running intermittently, usually these electromagnets cannot be excited for more than 40-50 seconds at a time.

After completion of 6 cycles, startup failure is activated and the relative warning light turns on.

Restore the fuel supply (release the lever or the motor stop button) and press the manual startup test pushbutton . Move the DIP switch 9 back to OFF.

Keep pressed the button  to check led test.

# DIAGRAM OF CONNECTION TO THE CONTROL TYPE C-12845-485

Basic indicative scheme. The right is reserved to change it without warning.

**CAPACITY OF CONTACTS MAX 5A (AC) 250 VAC**  
**WARNING!** The distance between the relay terminals is sufficient for a single insulation. Do not connect 230V lines near battery voltage lines (PELV, SELV).

- 71 AUTOMATIC MODE DISABLED
- 72 AUTOMATIC MODE DISABLED
- 73 AUTOMATIC MODE DISABLED
- 74 AUTOMATIC MODE DISABLED
- 75 STARTUP FAILURE
- 76 STARTUP FAILURE
- 77 MOTOR PUMP OPERATING
- 78 MOTOR PUMP OPERATING
- 79 MOTOR PUMP OPERATING
- 80 SWITCHBOARD FAULT
- 81 SWITCHBOARD FAULT
- 82 SWITCHBOARD FAULT
- 83 MINIMUM FUEL LEVEL
- 84 MINIMUM FUEL LEVEL
- 85 MINIMUM FUEL LEVEL

**CONTROL UNIT  
TYPE  
C-12845-485**

IN ALARM:(RELAY DISABLED)  
80-81 CLOSED  
80-82 OPEN

**IMPORTANT**  
TURN THE COMMUTATOR TO THE POSITION THAT CORRESPONDS TO THE NOMINAL VOLTAGE OF THE BATTERY (12 - 24V).


12 24  
VOLT

OUTPUTS  
5-7-11-13  
CAPACITY MAX 5A  
17-19  
CAPACITY MAX 3A

CONTROL UNIT  
SUPPLY

YOUR ELECTRICAL TECHNICIAN CAN ASK US ANYTHING ABOUT THIS PRODUCT BY TELEPHONING ONE OF OUR TECHNICIANS

- 30 PRESSURE SWITCHES CALL
- 32 PRIMING TANK FLOAT START-UP
- 33 AUTOMATIC STARTUP BLOCK WITH TERMINAL 33 CLOSED AT GROUND
- 37 FUEL FLOAT SET WITH VARIABLE RESISTANCE LEVEL INDICATOR OR CONTACT
- 39 THERMOSTATIC SWITCH SIGNALLING WATER OR OIL HEATER FAULT
- 50 PUMP PRESSURE SWITCH
- 51 OIL PRESSURE SWITCH
- 52 ENGINE THERMOSTATIC SWITCH
- 56 AVAILABLE FAULT: FOR PROGRAMMING SEE PAGE 11
- 57 OIL PRESSURE TRANSMITTER
- 58 WATER TEMPERATURE TRANSMITTER
- 59 OIL TEMPERATURE TRANSMITTER
- 66 BELT BREAKAGE (D+)
- 67 ENGINE RUNNING DETECTION PICK-UP AND TACHOMETER (W)
- 68 STARTER MOTOR PINION FAILURE TO ENGAGE
- 69



CONSULT STANDARDS CEI 44-5 (EN60204) FOR INFORMATION CONCERNING PROTECTION AGAINST OVERLOAD CURRENTS IN THE ELECTRICAL EQUIPMENT USING BATTERY VOLTAGE



# PROGRAMMABLE TIMES

DESCRIPTION	SECONDS	
	SETTING FIELD	FACTORY SETTING
DELAYED START AFTER OPENING OF THE CONTACTS OF THE CALL PRESSURE SWITCHES	1÷120	1
DELAY IN CLOSING OR OPENING THE CONTACT OF THE PRIMING TANK FLOAT	1÷10	1
<b>STARTING TIME</b> Start up attempt operation time	5÷10 sec.	5 sec.
<b>PAUSE TIME</b> Pause between start up attempts	5÷10 sec.	10 sec.
<b>STOP STAND-BY TIME (UNI 10779)</b>	1÷30 min.	20 min.
<b>CONTACT. 22-23-24 TIME</b> De-energization delay (stopped engine)	0÷600 sec.	0 sec.

## DELAYED START AFTER OPENING OF THE CONTACTS OF THE CALL PRESSURE SWITCHES.

ON Move DIP switch 2 to ON

**START DELAY FROM PRESS. SW.**

Press to display

Threshold

1 sec. ←

Delay

• Increases • Decreases

Press to change the time

ON Move DIP switch 2 to OFF

1 sec.

Press and wait for PROGRAMMED to be written.

## DELAY IN OPENING OR CLOSING OF THE PRIMING TANK FLOAT CONTACT.

ON Move DIP switch 2 to ON

**START DELAY FROM FLOAT**

Press to display

Threshold

1 sec. ←

Delay

• Increases • Decreases

Press to change the time

ON Move DIP switch 2 to OFF

1 sec.

Press and wait for PROGRAMMED to be written.

## STARTING TIME. START UP ATTEMPT OPERATION TIME.

ON Move DIP switch 2 to ON

**STARTING TIME**

Press to display

Time

5 sec. ←

• Increases • Decreases

Press to change the time

ON Move DIP switch 2 to OFF

5 sec.

Press and wait for PROGRAMMED to be written.

## PAUSE TIME. PAUSE BETWEEN START UP ATTEMPTS.

ON Move DIP switch 2 to ON

**PAUSE TIME**

Press to display

Delay

10 sec. ←

• Increases • Decreases

Press to change the time

ON Move DIP switch 2 to OFF

10 sec.

Press and wait for PROGRAMMED to be written.

## STOP STAND-BY TIME (UNI 10779).

ON Move DIP switch 2 to ON

**WAITING TIME STOP**

Press to display

Time

20 min. ←

• Increases • Decreases

Press to change the time

ON Move DIP switch 2 to OFF

20 min.

Press and wait for PROGRAMMED to be written.

## CONTACT 22-23-24 TIME. OPENING TIME OF CONTACT 22-24 AFTER DETECTION OF THE STOPPED ENGINE.

ON Move DIP switch 2 to ON

**CONTACT. 22-23-24 TIME**

Press to display

Time

0 SEC. ←

• Increases • Decreases

Press to change the time

ON Move DIP switch 2 to OFF

0 SEC.

Press and wait for PROGRAMMED to be written.

## IN-SITE ACTIVATION TEST

Start up and pause 15 NOT ADJUSTABLE seconds.

# PROGRAMMING

## CONTROL UNIT TYPE C-12845-485

### FUEL LEVEL. Variable-resistance float programming (T).

**ON** ↑ Move DIP switch 2 to ON

**EXAMPLE** NO FUEL

Press to display

Threshold

Intervention delay set by 1 ÷ 5 sec. 1% ←  
3 sec.

Increases Decreases

Press when the arrow is next to the parameter to be modified

**ON** ↓ Move DIP switch 2 to OFF

**EXAMPLE** 1%  
3 sec.

Press and wait for PROGRAMMED to be written.

FUNCTION	Factory setting	Warning light
• Max. fuel level	95%	OFF
• Min. fuel level	25%	FLASHING ON
• Fuel reserve	10%	STEADY ON
• No fuel	1%	STEADY ON

When the fuel level is lower 25% than the nominal filling level, the MIN. FUEL LEVEL alarm is enabled

PROGRAMME ONE LEVEL AT A TIME

WITH TERMINAL W WHEN THE CONTACT CLOSSES TO GROUND	WARNING LIGHT	DISPLAY
	FLASHING ON	MINIMUM FUEL LEVEL

### EVENT HISTORY

Data relating to the latest 100 events is collected.

**ON** ↑ Move DIP switches 2-5 to ON

**EVENTS HISTORY**

Press to display

Progressive number of faults that have occurred → **(Example)** N 12 ← Engine hour-meter

(Date) → **20-5-2008** 17:30 ← (Hour)

**LOW OIL PRESSURE**

Press this button to consult the events history. To be carried out with engine off.

**ON** ↓ Move all the DIP switches back to OFF.

### BOARD ADDRESS. Factory programming 1.

**ON** ↑ Move DIP switch 2 to ON

**BOARD ADDRESS**

Press to display.

1 ←

Increases Decreases

Press when the arrow is next to the parameter to be modified

**ON** ↓ Move DIP switch 2 to OFF

1

Press and wait for PROGRAMMED to be written.

### DIP - SWITCH

WAIT AT LEAST TWO SECONDS AFTER EACH MOVEMENT.

	TACHOMETER CALIBRATION	CHOICE •LAN-GUAGE •TIMES •THRESH-OLD	TRANSMIT-TERS TABLE	FUEL FLOAT T or W Float values table	INSTRU-MENTS EXCLU-SION	AVAILABLE PROTEC-TION	BATTERY VOLTAGE	STOP SYSTEMS	IN-SITE ACTI-VATION TEST	NOT USED IN REGULATION EN12845
<b>ON</b>							24 V	EXCITED IN DRIVE. WARNING STOP NOT CON-FORM TO THE EN 12845 STANDARD	<b>EN-GAGED</b>	
<b>OFF</b>							12 V	EXCITED IN STOP MODE	<b>EX-CLUDED</b>	


DIP 2 - 5 VIEW THE EVENTS HISTORY

## PROGRAMMING

**LANGUAGE SELECTION.** The factory set language is ITALIAN; the languages that can be selected are: **ENGLISH - SPANISH - GERMAN - FRENCH - PORTUGUESE.**

ON  Move DIP-switch 2 to ON

**SELEZIONE LINGUA ITALIANO**




STOP

Press to select the desired language

ON  Move DIP-switch 2 to OFF

**SELEZIONE LINGUA ENGLISH**



Press and wait for PROGRAMMED to be written.

### CALIBRATION:

#### TACHOMETER AND MOTORPUMP RUNNING THRESHOLD

Exclude the automatic startup using the relative switch.




Manually start the motorpump, then calibrate first the tachometers while the motorpump is in operation.

Stop the engine and calibrate the threshold of the motor pump in operation.

#### TACHOMETER REGULATION. Bring the engine to constant known revs (for example using a portable revs counter).

ON  Move DIP switch 1 to ON

**TACHOMETER REGULATION**



Set the engine revs read on the portable rev counter

3000 RPM


• Increases

STOP

• Decreases

ON  Move DIP switch 1 to OFF

3000 RPM




Press and wait for PROGRAMMED to be written.

#### MOTORPUMP RUNNING THRESHOLD CALIBRATION. Disconnects the starter motor.

ON  Move DIP switch 2 to ON

**ENGINE CALIBRAT. RUNNING**



Example  
Threshold 600 RPM


• Increases

STOP

• Decreases

ON  Move DIP switch 2 to OFF

600 RPM



Press and wait for PROGRAMMED to be written.

## AVAILABLE FAULT

THE NEW DESCRIPTION OF THE NAME OF THE FAULT IS NOT TRANSLATED.

ON  Move DIP switch 6 to ON

**CUMULATIVE ALARM**



The fault name description is finished

Press to read the functions and the delay to be programmed

#### HOW TO WRITE

0 1 2 3 4 5 6 7 8 9    A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

Press to choose a letter or number, release the key for at least 1 second; the letter or number will remain written on the display.

STOP

OPERATE MANUAL START TEST BUTTON IF LAMP IS LIT

Press to leave a space

Press to delete

RESET

#### FUNCTIONS TO BE PROGRAMMED DESCRIBED ON THE DISPLAY


#### DESCRIPTION

NOT STORED *	STORED	Choice of whether to store the cause of the alarm
<b>POLARITY</b> ACTIVE TO GROUND *	<b>POLARITY</b> ACTIVE OPEN	The probe intervenes when it closes or opens his own contact
<b>ACTIVATION</b> ALWAYS ACTIVE *	<b>ACTIVATION</b> ACTIVE RUNNING	Instant of probe activation
RELAY SWITCHING NOT ACTIVE (CONTACT 83-84-85)	RELAY SWITCHING' ACTIVE (CONTACT 83-84-85) *	Intervention lights up the cumulative flashing led  and switches over the contacts on the terminals <b>83</b> <b>84</b> <b>85</b>
<b>INTERVENTION RELAY</b> (ADJUSTABLE) 0 + 60 SEC. * FACTORY SETTING 10 seconds for the water reserve		The intervention occurs when the intervention delay has elapsed

Press to modify the functions and the intervention delay

STOP

ON  To confirm the programming move DIP switch 6 to OFF



Press and wait for PROGRAMMED to be written on the display

CONTROLAND MONITORING UNIT  
MOTORPUMP UNIT  
IN CONFORMITY TO EN12845 STANDARD  
**TYPE C-12845-485**

Carries out the automatic control and monitoring functions of a fire-fighting motorpump unit. It has been designed to be installed only inside on an electrical panel and to be connected to other components (contactors, battery chargers, etc.) which the installer will have available to complete the plant.

**NOTICES**



**Warning:**

**Components carrying dangerous voltage levels**

Only assigned and suitably trained personnel are allowed access to the control unit. No maintenance operations are permitted unless the plant is disconnected from the mains and the battery. As an additional safety measure, the plant phases should be short-circuited and earthed. Notwithstanding the above, only assigned and trained personnel can perform the following operations with the plant on:

- make a visual inspection of the control unit, the connections and their markings.
- measure the voltage and/or current values.

These interventions, however, must be performed using equipment which ensures appropriate levels of electrical protection.



**Warning:**

**adhere closely to the following advice**

- At the point of mains installation, the presumed short circuit current must not exceed 10kA.
- All technical interventions on the motorpump must be performed with the engine stationary and terminal 50 of the start motor disconnected.
- Check that the user equipment power consumption is compatible with the technical features described.
- Install in such a way that there is always adequate heat disposal.
- Always install under other equipment which produces or spreads heat.
- Make sure that no copper conductor cuttings or other waste material fall inside the equipment.
- If necessary, the fuses must only be replaced with the same type as the original.
- Never disconnect the terminals of the battery with engine running.

**THIS CONTROL UNIT IS NOT SUITABLE FOR OPERATING IN THE FOLLOWING CONDITIONS:**

- Where the environmental temperature is outside the limits specified in the present technical manual.
- Where the air pressure and temperature variations are so rapid as to produce exceptional condensations.
- Where there are high levels of pollution caused by dust, smoke, vapour, salts and corrosive or radioactive particles.
- Where there are high levels or heat from radiation caused by the sun, ovens or the like.
- Where attacks from mould or small animals are possible.
- Where there is the risk of fire or explosions.
- Where the switch-board can receive strong vibrations or knocks.

**CONDUCTION AND MAINTENANCE**

The following maintenance operations should be performed every week:

- automatic start;
- check that the indicators function;
- check the batteries;
- check that the conductors are tight, check the condition of the terminals.

**ELECTROMAGNETIC COMPATIBILITY**

This control unit functions correctly only if inserted in plants which conform with the CE marking standards; it meets the exemption requirements of the standard EN50082-2 but it cannot be excluded that malfunctions could occur in extreme cases due to particular situations.

The installer has the task of checking that the disturbance levels are within the requirements of the standards.

**NOTE CONCERNING CONNECTION OF COMMAND AND SAFETY DEVICES TO THE PANEL**

With the direct connection of engine protection probes and remote control and command contacts to the control switch-board, particular anomalous situations (earth anomalies or interruption of electrical connections) could block the start-up or provoke its early activation.

To reduce these risks, if he believes it to be necessary, the installer can take on the responsibility of applying that which is described in paragraphs 9.4.2.1 and 9.4.2.2 of standard CEI EN60204-1 (CEI 44-5) to the said connections.

**UNLESS WE MAKE A WRITTEN DECLARATION STATING THE CONTRARY, THIS CONTROL UNIT IS NOT SUITABLE FOR USE AS A CRITICAL COMPONENT IN EQUIPMENT OR PLANTS RESPONSIBLE FOR KEEPING PERSONS OR OTHER LIVING BEINGS ALIVE**

Any use which differs from that which is indicated in this instruction and user manual must be authorized by us to the manufacturer.

**YOUR ELECTRICAL TECHNICIAN CAN ASK ANY QUESTIONS ABOUT  
THIS CONTROL UNIT BY TELEPHONING OUR TECHNICIAN**

## TECHNICAL DATA

TWO BATTERIES SUPPLY VOLTAGE AT SUPPLY VOLTAGE	12 VDC and 24 VDC 8 ÷ 32 VDC
CIRCUIT LOADING WITH ENGINE STATIONARY MAXIMUM LOADING	70 mA at 12V 40 mA at 24V 130 mA at 12V 70 mA at 24V
CAPACITY OF CONTACTS 5-7-11-13	MAX 5A 25 VAC 60 VDC
CAPACITY OF CONTACTS 17-19	MAX 3A 25 VAC 60 VDC
CAPACITY OF CONTACTS from 71 to 85	MAX 5A (AC1) 250 VAC
DEGREE OF REAR PROTECTION	IP 20
DEGREE OF FRONT PROTECTION	IP 64
TEMPERATURE RANGE	-10 ÷ +60 °C
HOUR METER	4 DIGITS
TACHOMETER	4000 rpm ± 15 rpm
BATTERY CHARGERS VOLTMETERS	MAX 38 V Precision 5%
BATTERY CHARGERS AMMETERS	MAX 99 A Precision 5%
OIL PRESSURE GAUGE, WATER AND OIL THERMOMETERS, AND FUEL LEVEL INSTRUMENTS PRECISION	2%
SERIAL COMMUNICATION PARAMETERS	9600 baud, 8 bit data, 1 bit stop; EVEN parity
INSTALLATION CONDITIONS	INSIDE FOR INTERNAL USE
WEIGHT	850 gr
DIMENSIONS	L243 x H170 x P62
HOLE	227X155

## ORDERING DATA

TYPE C-12845-485

Code 00242291

## ACCESSORIES KIT

KIT MU-C-12845-485

Code 40804523

## CONFORMITY DECLARATION



ELCOS s.r.l. assumes full responsibility for declaring that the equipment:

type **C-12845/485**

installed and used in the ways and for the purposes described in the instruction and user manual, is in conformity with the following directives:

<b>2014/35/UE</b>	on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits
<b>2014/30/UE</b>	on the harmonisation of the laws of the Member States relating to electromagnetic compatibility
<b>2011/65/UE</b>	on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS).

because it is built and functions in accordance with the harmonized Standards:


<b>EN 12845:2015</b>	Fixed firefighting systems - Automatic sprinkler systems - Design, installation and maintenance
<b>EN 61010-1:2010</b>	Amendment 1 - Safety requirements for electrical equipment for measurement, control, and laboratory use - Part 1: General requirements.
<b>EN 60529:1997</b>	Degrees of protection provided by enclosures (IP Code)
<b>EN 61326-1:2012</b>	Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements
<b>EN 61000-6-2:2016</b>	Generic standards - Immunity standard for industrial environments

tests of:

<b>EN 61000-4-2:2008</b>	Electrostatic discharge immunity test
<b>EN 61000-4-3:2006</b>	Radiated, radio-frequency, electromagnetic field immunity test
<b>EN 61000-4-4:2012</b>	Electrical fast transient/burst immunity test
<b>EN 61000-4-5:2014</b>	Surge immunity test
<b>EN 61000-4-6:2013</b>	Immunity to conducted disturbances, induced by radio-frequency fields
<b>EN 61000-4-8:2009</b>	Power frequency magnetic field immunity test
<b>EN 61000-4-11:2004</b>	Voltage dips, short interruptions and voltage variations immunity tests
<b>EN 61000-6-3:2006</b>	Generic standards - Emission standard for residential, commercial and light-industrial environments
<b>EN 55022:2012</b>	Information technology equipment - Radio disturbance characteristics - Limits and methods of measurement

## 6. APPENDED 1 –ASSOCIABLE CONTACT

# ASSOCIABLE CONTACT



Possibility of associating to the contact the function:

## MOTORPUMP IN OPERATION

The intervention:

- switches on the led, 
- is indicated on the display

**CONTACT 22-23-24  
RUNNING ENGINE**

- switches the contact with the pump in operation

**22 24** CLOSED

**22 23** OPEN

SETTING FACTORY  
C-12845-485

or

## GENERAL ALARM

The intervention:

- switches on the led, 
- is indicated on the display

**CONTAT. 22-23-24  
GENERAL ALARM**

- switches the contact with the general alarm occurred

**22 23** CLOSED

**22 24** OPEN

SETTING FACTORY  
C-12845-485

or

## FAN CONTROL

The intervention:

- is indicated on the display

**CONTAT. 22-23-24  
FAN CONTROL**

- Switches the contact when the engine is running (detected by the Pik up)

**22 24** CHIUSO


**22 23** APERTO

The relay returns to its normal state after the set time.


### CHOICE OF THE FUNCTION TO ASSOCIATE TO THE CONTACT

ON  Move DIP switch 2 to ON

**CONTACT 22-23-24  
RUNNING ENGINE**



**CONTACT 22-23-24  
GENERAL ALARM**



ON  Move DIP switch 2 to OFF

**CONTACT 22-23-24  
GENERAL ALARM**



RUNNING ENGINE

GENERAL ALARM

FAN CONTROL

.Associated with "Contact 22-23-24 time"  
See page 8 of the manual.

## 7. APPENDED 2 – EVENTS HISTORY

# ZEROING HISTORICAL REPORT (visible with remote management) CONTROL UNIT C-12845-485 C-12845/1200 C-10845

## ZEROING HISTORICAL REPORT

Data relating to the latest 100 events is collected.

- List of events:
- START-UP BYPRESS. SWITCHES
  - START-UP DAPRIMING
  - START-UP BUTTON
  - START-UP WEEKLY TEST
  - STOP MANUAL
  - STOP AUTOMATIC
  - SENSED ALARMS

### TO BE CARRIED OUT WITH ENGINE OFF



Move DIP switches 2 - 5 to ON



Press to display

Progressive number of faults that have occurred → (Example) **N 12** ← Engine hour-meter  
Date → **20-05-2008** **17:30** ← Hour




Press this button to consult the events history.

### ACCESS TO THE ZEROING OF THE HISTORICAL REPORT



Move DIP switches 2 - 4 to ON



Press for at least 15 sec., until the hour-meter flashes.

Release the key, the display still shows the hour-meter, which no longer flashes.




Press again, the historical report will reset.



Move all the DIP switches back to OFF.

# CALENDAR CLOCK ADJUSTMENT

Adjustment is recommended . The time and date are used when the historical report is displayed.



Calendar clock adjustment



If the power is cut off, adjustment of the calendar clock must be repeated

## 8. APPENDED 3 – WEEKLY AUTOMATIC TEST

# WEEKLY AUTOMATIC TEST

PREPARATION  
FOR AUTOMATIC  
WEEKLY TEST

CUT THE  
JUMPER A

IF THE JUMPER IS CUT,  
THE BOARD NO  
LONGER COMPLIES  
WITH THE EN12845  
STANDARDS

## DIP - SWITCH (Control Unit C-12845-485 - C-12845/1200 - C-10845) WAIT AT LEAST TWO SECONDS AFTER EACH MOVEMENT.

	TACHOMETER CALIBRATION	CHOICE • LANGUAGE • TIMES • THRESHOLD	TRANSMITTERS TABLE	FUEL FLOAT T or W Float values table	INSTRUMENTS EXCLUSION	AVAILABLE PROTECTION	BATTERY VOLTAGE	STOP SYSTEMS ⚠ EXCITED IN DRIVE. WARNING STOP NOT CONFORM TO THE EN 12845 STANDARDS	IN-SITE ACTIVATION TEST	WEEKLY AUTOMATIC TEST
ON							24 V		EN-GAGED	EN-GAGED
	1	2	3	4	5	6	7	8	9	10
OFF							12 V	EXCITED IN STOP MODE	EX-CLUDED	EX-CLUDED

### OPERATION

Setting the relevant lever on TEST ENGAGED, the engine starts up after 1 second and stays on during the WEEKLY TEST DURATION (programmed at 5 minutes).

This test will be repeated automatically every week on the exact day and at the hour to which the TEST ENGAGED lever has been positioned. During the automatic test cycle, **WEEKLY SELFTEST** is shown on the display.

**WARNING:** whenever the battery voltage is cut off from the control unit, the time elapsed from the moment when lever 10 was set to ON is **reset to zero**. The count of the weekly time starts again from the moment when the control unit is supplied with power.

**OPERATION:** the motorpump starts up, if during the test a fire call occurs, the motorpump stays on up to the manual stop. The Stop button is enabled at all times. When it is pressed, the test is cancelled and it will be repeated the following week.

#### WITH THE CUMULATIVE WARNING LIGHT ON:

- the weekly test is cancelled, and will be repeated the following week after the fault has been reset.
  - the engine is stopped, when an anomaly intervenes during the test.
  - the engine is not stopped when the switch is positioned on AUTOMATIC MODE EXCLUDED.
- When the switch is positioned back to AUTOMATIC START UP ENGAGED, the engine continues to run.
- the automatic starting of the engine is not prevented.

SWITCHING ON OF THE WARNING LIGHT CAUSED BY MODEM ANOMALIES, WHICH DO NOT CANCEL THE WEEKLY TEST AND DO NOT STOP THE ENGINE.

**Failure to start during the test** is the only fault with the automatic reset. The reset occurs after the call from the pressure switches or from the priming tank float.

- The test is cancelled if it starts when the pump is already running; it will be carried out the following week.

**WEEKLY TEST DURATION.**  
When the test time is up, the engine stops.

- REGULATION RANGE 2 ± 60 minutes.
- FACTORY SETTING 5 minutes.

ON ↑ Move DIP switch 2 to ON

WEEKLY SELFTEST TIME

Press to display

Time

5 min

←

ON ↓ Move DIP switch 2 to OFF

5 min

Press and wait for PROGRAMMED to be written

• Increases Press to change the time

• Decreases

RESERVED TO THE MANUFACTURER


## 9. APPENDED 4 – SPECIAL FUNCTIONS AND RESTORATION

# EXCLUSION OF INSTRUMENTS AND FUNCTIONS CONTROL UNIT TYPE C - 12845-485 C-12845/1200 - C-10845

It is possible to exclude instruments by following the procedures below.

## EXCLUSION PROCEDURE


ON ↑  Move DIP switch 5 to ON

EXAMPLE  

**OIL PRESS. GAUGE**

Press to display the instrument to be excluded

ON ↓  Move DIP switch 5 back to OFF

EXAMPLE  

**OIL PRESS. GAUGE**


Press and wait for EXCLUDED to be displayed

OIL PRESS. GAUGE

EXCLUDED


## PROCEDURE FOR CANCELLING THE EXCLUSION


ON ↑  Move DIP switch 5 to ON

EXAMPLE  

**OIL PRESS. GAUGE**

Press to display the EXCLUDED instrument

ON ↓  Move DIP switch 5 back to OFF

EXAMPLE  

**OIL PRESS. GAUGE**

Press and wait for ENGAGED to be displayed

OIL PRESS. GAUGE

ENGAGED

## EXCLUDABLE INSTRUMENTS AND FUNCTIONS

FACTORY SETTING	
EXCLUDED	• OIL PRESSURE GAUGE
“	• ENGINE WATER THERMOMETER
“	• ENGINE OIL THERMOMETER
“	• PUMP PRESSURE SWITCH
ENGAGED	• TACHOMETER
“	• STARTUPS COUNTER
“	• FUEL LEVEL INDICATOR
“	• BATTERY A VOLTMETER
“	(1) • BATTERY B VOLTMETER
“	• BATTERY A AMMETER
“	(1) • BATTERY B AMMETER
“	- CHARGER BATTERY A NOT TRANSMITTING
“	(1) - CHARGER BATTERY B NOT TRANSMITTING
“	- PICK UP INTERRUPTED
“	- PINION CIRCUIT BROKEN (disable if not connected to terminal 69)
EXCLUDED	- STOPPING FROM FLOAT (stopping at the reopening of the priming float)

 **WARNING THE EN12845 STANDARD DOES NOT PROVIDE FOR THIS STOPPING** (before to engage this function, read the enclosure G)

(1) - Functions not present in version C-10845

RESERVED TO THE MANUFACTURER


# PROGRAMMING OF PRESSURE AND TEMPERATURE TRANSMITTERS CONTROL UNIT

## TYPE C - 12845-485 C-12845/1200C-10845


The control unit is factory set for pressure and temperature transmitters such as TYPE TPO/403 (Pressure), TTAO/402 (Temperature).

It is possible to programme 10 resistance values, corresponding to the characteristic curves of other pressure and temperature transmitters.


### PROGRAMMING OF CORRESPONDENCE




### OIL TEMPERATURE TRANSMITTER



### WATER TEMPERATURE TRANSMITTER



### OIL PRESSURE TRANSMITTER



### TO RESTORE THE TABLES TO THE FACTORY VALUES, DELETE ALL THE 10 PROGRAMMINGS

**CAUTION:** It is necessary to programme at least 2 values (To obtain a good precision in temperature and pressure control we recommend programming at least 4 values). With less than 2 values programmed, "ERROR" will be displayed and the factory-set programming will be maintained.

### STARTUP COUNTER RESETTING

**STARTUP COUNTER BATT. A N 6500**





**STARTUP COUNTER BATT. B N 6500**

# PROGRAMMING


## CONTROL UNIT TYPE C - 12845-485 -C-12845/1200 C-10845

### SELECTION OF FUEL FLOAT

The control unit is programmed for a float/rheostat assembly (suitable for the fuel level indicator).  
 During programming FUEL CONTROL **T** will be shown on the display.  
 It is possible to programme the use of a float with a contact that closes to ground when there is no fuel.  
 During programming FUEL CONTROL **W** will be displayed.



OR




Press to display

Press and wait for PROGRAMMED to be written

## FUEL FLOAT PROGRAMMING



The factory control unit is adjusted for floats type GR ... made by Elcos (300 Ohm empty tank - 100 Ohm for half-full tank - zero Ohm full tank).  
 It is possible to programme 11 resistance values, corresponding to the characteristic curves of other floats.

### PROGRAMMING OF CORRESPONDENCE



**TO RESTORE THE TABLES TO THE FACTORY VALUES, DELETE ALL THE 11 PROGRAMMINGS**

**CAUTION:** It is necessary to programme at least 2 values (to obtain a good precision in temperature and pressure control we recommend programming at least 4 values) With less than 2 values programmed, "ERROR" will be displayed and the factory-set programming will be maintained.



# RESTORE FACTORY-SET PROGRAMMING

TO RESTORE ALL THE FACTORY-SET PROGRAMMING



Move DIP switches  
1-3-5-7-9 to ON



Press for at least 1 second, until  
the writing STANDARD appears



MOVE ALL THE DIP  
SWITCHES BACK  
TO OFF

PROGRAMMING OF THE FOLLOWING IS NOT RESTORED:

- LANGUAGE
- OPERATING HOURS
- STARTUPS COUNTER



**ELENTEK SRL SOCIETÀ UNIPERSONALE**

Via A. Meucci 5/11 - 35028 Piove di Sacco (PD) - ITALIA

Tel. +39 049 9730367 - Fax +39 049 9731063

[www.elentek.com](http://www.elentek.com) - [info@elentek.com](mailto:info@elentek.com)

P.IVA 04534630282

*Cod. MQ EN 0002 UK*

*Rev. 02*

*Em. 10.2020*